A series maintenance schedule

For the Bambu Lab A1 and A1 mini. Every interval on this sheet comes from Bambu Lab's own maintenance pages.

SERIES

A | P | X | H

The schedule FIND YOUR COLUMN

Task	A1	A1 mini
Part cooling fans Look at the blades and around them; clear built-up dust or debris.	**Weekly**	**Weekly**
Linear rails Clean them with tweezers and a lint-free cloth, re-oil and move the axis to spread the oil. Never grease the X rail.	**Monthly** X rail and Y guide rails	**Monthly** X rail, Y guide rails and Z rail
Z lead screws Grease the working area, then run Z up and down so all of it is coated.	**Every 3 months** two lead screws	**Every 3 months** one lead screw
Extruder gear Clean the filament dust off the gear.	**Every 5 spools** every 2 spools with carbon fiber filaments	**Every 5 spools** every 2 spools with carbon fiber filaments
Filament cutter blade Check the blade; replace it when it is dull.	**Every 3 spools** of PLA, ABS or PETG	**Every 3 spools** of PLA, ABS or PETG
Belts Re-tension a belt when the printer flags it as loose; replace a belt with obvious wear that affects print quality.	**When the printer prompts** the calibration checks belt tension itself	**When the printer prompts** the calibration checks belt tension itself
Nozzle wiper A damaged wiper leaves the nozzle tip dirty.	**When damaged** replace it once it is damaged or deformed	–

– = no interval for this model on the Bambu pages we cite. Oil for the rails: the lubricant oil that comes with the printer. Bambu also allows the original WD-40 Multi-Use Product on the X rail, the Y guide rails and the Z lead screw, and says it has not tested other oils.

Not on this sheet. A2L: our guides do not list Bambu's A2L intervals yet, so this sheet leaves it out. Follow Bambu Lab's wiki for the A2L.

Every A series printer SAME FOR EVERY MODEL

Hotend
When worn

Replace it when the tip is worn or damaged, or extrusion stays inconsistent after cleaning and calibration. Carbon fiber, glass fiber and particle-filled filaments need a hardened steel nozzle.

Nozzle buildup
When buildup shows

Wipe the tip with Bambu's Hotend Cleaning Sponge, used wet. Bambu says the sponge works with the nozzles of all its printers.

Textured PEI plate
When adhesion drops

Wash it with warm water and dish soap; Bambu prefers this to IPA alone, which can spread finger oils. Clean only a cool plate.

Sources BAMBU LAB WIKI, VERSION WE CITE

wiki.bambulab.com/en/a1/maintenance/basic-maintenance 2026-09-29
wiki.bambulab.com/en/a1-mini/maintenance/period-maintenance
wiki.bambulab.com/en/a1/maintenance/lubricate-y-axis
wiki.bambulab.com/en/filament-acc/acc/pei-plate-clean-guide
wiki.bambulab.com/en/general/nozzle-cleaning-sponge

Maintenance log PRINT IT, FILL IT IN

Date	Task	Printer	Notes

How to do each job, step by step:
bambuhub.net/guides/routine-maintenance

Independent resource for Bambu Lab owners, not affiliated with Bambu Lab. Intervals from the Bambu Lab Wiki pages listed above, as cited in our routine maintenance guide (updated October 11, 2026) and our planner at bambuhub.net/tools/maintenance. Bambu updates these pages: if your printer or Bambu's wiki says something else, follow Bambu.

bambuhub bambuhub.net

Status: Independent

Guide updated: October 11, 2026

Scan for the guide